

PVMC


Module Security Cover







Caution:The break-off pieces may fly off while twisting.Take reasonable precautions to prevent any flying pieces from causing injury.

Example 1
All break-offs removed.







Typical Module Feed wires through cover before making connections. Use 12mm screws. (Actual Size)

Covering for Empty Bay

Break sections off as needed to expose connector.