

NQ-SMS1810-VF Speaker Installation Instructions

Preparation

1. *Upward-firing Operation:* Use as shipped. (Figure 1)
2. *Downward-firing Operation:* Relocate hangers to the bottom of the assembly. (Figure 2)
3. *Side-firing Operation:* Relocate one hanger to the bottom of the assembly. (Figure 3)



Figure 1:
Upward-firing operation



Figure 2:
Downward-firing operation



Figure 3:
Side-firing operation

Installation

1. Determine a structurally sound hang point for the enclosure.
2. Install to the desired height using the hanging chain.

Note: AHJ/local codes may require a secondary tie-off to the structure.

Electrical connection

1. Feed the supply cable through whip (if required) to connector.
2. Select speaker leads for desired system type: 70V – Red, 25V – Yellow, and COM – Black. Interconnect the speakers in the system, making sure that all leads of the same color are connected. Avoid swapping colors.
3. Cut bare wire tip off of unused speaker lead. Feed connection points through the clamp into the enclosure and tighten the clamp screws.
4. Rotate the switch to the desired power setting.

Product has been tested to UL Standard 2043.